

Material

Base material teak wood, oak wood

Dimensions


Weight


20 kg

SPECIFICATIONS

teak wood, oak wood

360 x 360 x 510 mm







FULL RANGE SOUND OUTPUT

Speaker type

6" dual-concentric speaker

Nominal impedence

80

Crossover

two way on board

Frequency range

38-20.000 Hz (-6dB)

Sensitivity (1W-1m)

89 dB

Speaker Peak Power

300W

Speaker RMS Power

150W

Recommended amplifier power

200W (Class D)

SUBWOOFER SOUND OUTPUT

Speaker type

6" Woofer

Nominal impedence

8.0

Crossover

no crossover on board - DSP needed (HP 35 Hz 12dB/oct min; LP 120 Hz 12 dB/oct min)

Frequency range

38-150 Hz (-6dB)

Sensitivity (1W-1m)

89 dB

Speaker Peak Power

300W

Speaker RMS Power

150W

Recommended amplifier power

200W (Class D)

Unpacking: to remove the Block from the shipping box carefully follow these steps



 Gently lift the wooden deflector from the packaging.



2.
Turn it and place into position on the floor.




3. Pull the Block out of the box holding its base firmly.




4. Turn the Block and place it into position on top of the deflector.

Output cable: The Block can have two types of connection for the cable:


- SpeakOn connector is particularly is suitable for both indoor and outdoor installations.
- Hi-Fi Binding Posts (gold plated) is an optional connection typology, only for indoor installations.





Hi-Fi Binding Posts

Diffusion and directionality: Cubes are characterized by a dual-concentric 6" transducer, where the mid-woofer and the tweeter share the same axis, to achieve a virtually punctiform source, linear and time coherent, which, combined with the deflection system, ensures an ideal omnidirectional emission. The result is a very natural sound, not constrained to any fixed and obligated listening positions, with an amazing quality and clarity unusual in outdoor environments. It is recommended to place these modules, either indoor or outdoor, directly on the floor; indoor it is usually recommendable to position them at least 0,6-1 meter from each wall to enhance soundstage and clarity.



Maintenance and care: to keep your speakers beautiful as long as possible, we warmly recommend doing maintenance at least once a year. When not in use, sound modules should be appropriately covered or stored away; heavy duty protective covers are available from AS.

> Please refer to the General Manual for appropriate instructions and note that any departure from our recommendations on care and cleaning, or any evidence of misuse or damages from ordinary wear and tear, will void all warranty claims.



